

**FPU® SYSTEMS OPERATION MANUAL
(INCLUDING REPAIR PARTS & SPECIAL TOOL LIST)
Small Cabinet Module (SCM)
BOH FPU Field Pack-up Units**

**CHAPTER 3
TROUBLESHOOTING PROCEDURES**

This page was intentionally left blank

TROUBLESHOOTING PROCEDURES
FPU® SYSTEMS OPERATION MANUAL
(INCLUDING REPAIR PARTS & SPECIAL TOOL LIST)
SMALL CABINET MODULE (SCM)
BOH FPU Field Pack-up Units

INTRODUCTION

INTRODUCTION

The malfunction/symptom index in WP 0011 00 is a quick reference for finding the troubleshooting procedures. Associated with each symptom name is a table number representing the starting point in a troubleshooting sequence contained in WP 0012 00. The troubleshooting index is broken down by component. Find the component and malfunction/symptom, review the referenced table for the test or inspection and perform the corrective action. This type of activity continues until successful fault isolation is achieved.

Troubleshooting Procedures

The troubleshooting work package contains tables listing the malfunctions, checks or inspections, and corrective actions required to return the equipment to normal operation. Perform the steps in the order they appear in the tables.

The work package is headed by an initial setup. This setup outlines what is needed as well as the conditions that must be met before starting the task. **DO NOT START A TASK UNTIL:**

- You understand the malfunction.
- You understand what you need to do to correct the malfunction.
- You understand what is needed to do the work.
- You have the things you need.

This manual cannot list all malfunctions that may occur or all tests, inspections and corrective actions. If a malfunction is not listed, or is not corrected by listed corrective actions, notify unit maintenance.

END OF WORK PACKAGE

This page was intentionally left blank

This page was intentionally left blank

TROUBLESHOOTING PROCEDURES
FPU® SYSTEMS OPERATION MANUAL
(INCLUDING REPAIR PARTS & SPECIAL TOOL LIST)
SMALL CABINET MODULE (SCM)
BOH FPU Field Pack-up Units

TROUBLESHOOTING PROCEDURES TABLE 1

INITIAL SETUP:**Materiel/Parts**

None

Personnel Required

Two

Tools

General Mechanic's Tool Kit

References

None

Equipment Condition

MODULE setup

NOTE

If malfunction corrective action does not correct the malfunction, notify unit maintenance.

TABLE 1 OPERATOR TROUBLESHOOTING

Malfunction	Test or inspection	Corrective action required
1. Unable to insert a drawer in the tray.	Check for debris in the tray.	Clear debris in the tray.
	Ensure the tray bumpers are fully installed.	Reinstall the bumpers.
2. Unable to latch the drawer lid.	Inspect for debris or material above the top of the drawer dividers.	Clear, align or rearrange material, or remove excess material.
3. Drawer trays are difficult to pull out or push in.	Inspect for dirt, sand, grit on the drawer slides of the drawer trays.	Remove drawer, clean tray slides as required with soap and water. Wipe dry with rags, lubricate drawer slides and tracks.
	Ensure the drawer is aligned in the tray properly.	Remove the drawer and align the drawer in the tray.
	Inspect for slide damage.	Report to Unit Maintenance for slide replacement.
4. Drawer rolls back when extended.	Ensure the drawer tray is fully extended, check for dirt and corrosion in slide detent.	Pull drawer, to the fully extended position, clean dirt from slide detent, lubricate drawer slide.
5. Moisture in drawer.	Inspect drawer lid seal for damage, dirt, gravel.	Clean or replace seal as necessary.

TABLE 1 OPERATOR TROUBLESHOOTING (cont'd)

Malfunction	Test or inspection	Corrective action required
6. Drawer slam latch will not latch or unlatch smoothly.	Inspect the slam latch for dirt, rust or damage.	Clean and lubricate, or replace if damaged.
7. Unable to insert a hull assembly.	Inspect hull bottom tracks and bezels for dirt and debris.	Clean hull tracks, tops and bezel with damp rags.
	Inspect hull bezels for damage.	Repair or replace bezel assembly
8. Drawer is not set properly in the tray.	Inspect the edge protector to see whether they have come loose or are out of position.	Remove the existing adhesive from edge protector. Apply adhesive Turbo Fuse series 130PR and reattach.
Slide Tape worn or damaged	Inspect slide tape for ware or damage	Replace slide tape. Apply adhesive Turbo Fuse series 130PR and reattach.
End Of Table		

END OF WORK PACKAGE